

RAYNOX Camcorder Cross Reference Table for Wideangle Lens

Camera Maker	Camera Model	DVR-5002(0.5x)	DCR-5000(0.5x)	HD-5050PRO(0.5x) / HD-5050PRO-LE(0.5x)	HD-6600PRO-43/49/52/55/58(0.66x)	DCR-730(0.7x)	DVM-700(0.7x)	HD-7062PRO(0.7x)	HD-7000PRO(0.7x)	DCR-7900ZD(0.79x)	HDP-6000EX(0.79x)	DVR-1002(0.65x+1.5x)	QC-505(0.5x) QC-707(0.7x)	XL-5000PRO(0.5x) XL-7000PRO(0.7x)	
SONY	HDR-FX1000(E), HVR-Z5(E)(U)										Direct mount				
	HDR-FX7(E), HVR-V1(U)(E)(N)		RA5262A			RA5262A		Direct mount			RA7262			Direct mount*4	
	HDR-CX7(E)(EK)(K)(KE)/CX6EK	Direct mount*1	RA5237A	Direct mount *1	HD-6600PRO-52+RA5237A	RA5237A			RA5837				Direct mount	Direct mount	
	HDR-UX20			RA3730(Included)											
	HDR-UX1	RA3730(Included)		RA3730(Included) *1			Direct mount *1					RA3730(Included)	Direct mount		
	HDR-SR12(E)/SR11(E)/CX12(E)		RA5237A	Direct mount	HD-6600PRO-52+RA5237A	RA5237A			RA5837						
	HDR-SR8(E)/SR7(E)	Direct mount*1	RA5237A	Direct mount *1	HD-6600PRO-52+RA5237A	RA5237A			RA5837				Direct mount	Direct mount	
	HDR-SR1	RA3730(Included)		RA3730(Included) *1			Direct mount *1						RA3730(Included)	Direct mount	
	HDR-HC3	RA3730(Included)		RA3730(Included) *1			Direct mount *1						RA3730(Included)	Direct mount	
	HVR-Z7(E)/S270(E)											Direct mount			
	HDR-FX1,HVR-Z1(E)(U)										RA6272	Direct mount			
	HDR-HC9(E)/HC7(E)/CX7, HDR-UX7(E)/HC5(E)/UX5(E)	Direct mount*1	RA5237A	Direct mount *1	HD-6600PRO-52+RA5237A	RA5237A			RA5837				Direct mount	Direct mount	
	HDR-HC1, HVR-A1		RA5237A	Direct mount *1	HD-6600PRO-52+RA5237A	RA5237A			RA5837						
	HDR-CX110/150/155E/116E/115E HDR-XR150/155E			RA3730(Included)	HD-6600PRO-52+RA5237A+RA3730	HD-6600PRO-52+RA5237A+RA3730								Direct mount	
	HDR-XR100(E)/105(E), HDR-CX100(E)/105(E)			RA3730(Included) *1											
	HDR-XR500V(E)/520V(E), CX500V(E)/520V(E)				HD-6600PRO-52+RA5237A	RA5237A									
	DCR-DVR508/DCR-DVD908(E)	Direct mount	RA5237A	Direct mount	HD-6600PRO-52+RA5237A	RA5237A			RA5837				Direct mount	Direct mount	
	DCR-DVD405/403/505	RA3730(Included)		RA3730(Included)			Direct mount						RA3730(Included)	Direct mount	
	DCR-DVD308/DCR-DVD708(E)	RA3730(Included)		RA3730(Included)			Direct mount						RA3730(Included)	Direct mount	
	DCR-SR300(C)(E)	Direct mount	RA5237A	Direct mount	HD-6600PRO-52+RA5237A	RA5237A			RA5837				Direct mount	Direct mount	
	DCR-SR62(E)	RA3730(Included)		RA3730(Included)			Direct mount						RA3730(Included)	Direct mount	
	DCR-SR100/SR60	RA3730(Included)		RA3730(Included)			Direct mount						RA3730(Included)	Direct mount	
	DCR-HC62(E)/DVD810			RA3730(Included)											
	DCR-HC96/90	RA3730(Included)		RA3730(Included)			Direct mount						RA3730(Included)	Direct mount	
	DCR-HC48	RA3730(Included)		RA3730(Included)			Direct mount						RA3730(Included)	Direct mount	
	DCR-VX2100/2000/PD-170/ PD-150/DSR-250		RA5258A		HD-6600PRO-58*6	RA5258A			Direct mount						Direct mount
	DCR-VX1000				HD-6600PRO-52										Direct mount
DCR-TRV950/PDX10		RA5237A	Direct mount	HD-6600PRO-52+RA5237A	RA5237A			RA5837					Direct mount	RA5237A	
PMW-EX1(E)															
Canon	HF11/10/100/HG21			RA3737(Included) *1											
	HF20/21				RA5237A	RA5237A									
	HF S10/11/100					RA5258A			Direct mount						
	XH-G1/ XH-A1											Direct mount			
	XL1/XL2/XL H1 16X*20X Zoom											Direct mount			
	HV30/HV20/HG10		RA5243B		HD-6600PRO-52+RA5243B	RA5243B			RA5843						
	HV10	Direct mount*5*6		Direct mount*5*6		RA5237A							Direct mount		
	HR10	Direct mount*5*6		Direct mount*5*6	HD-6600PRO-52+RA5237A	RA5237A							Direct mount	Direct mount	
	DM-DC40	Direct mount		Direct mount									Direct mount	Direct mount	RA5237A
	DM-DC20	RA3727P5(Included)		RA3727P5(Included)				RA3027P5(Included)					RA3727P5(Included)	Direct mount	
	DM-FV500(ZR 100/MV 790/800/800i)	RA3728P5		RA3728P5									RA3728P5	Direct mount	
	IXY DV M5(Optura 600A/MVX IE)	RA3734P5(Included)		RA3734P5(Included)									RA3734P5(Included)	Direct mount	
	IXY DV S1(Optura S1/MVX1S1)	RA3727P5(Included)		RA3727P5(Included)				RA3027P5(Included)					RA3727P5(Included)	Direct mount	
	IXY DV5(EIura 50/MV 6iMC) DV3(EIura 40MC/MV5iMC)	RA3728P5		RA3728P5									RA3728P5	Direct mount	
	FV M300(EIura 100/MVX 430/450/460)	RA3727P5(Included)		RA3727P5(Included)				RA3027P5(Included)					RA3727P5(Included)	Direct mount	
	FV M1(Optura XI/MVX3i)				HD-6600PRO-52+RA5246										RA5246
	XV-1(GL1/XM1)/XV-2(GL2/XM2)		RA5258A		HD-6600PRO-58	RA5258A			Direct mount						Direct mount
	PV130														RA5243B

*1:Vignetting occurs at 4:3 Still mode *2:Vignetting occurs at Still/Video/under scanning mode *3:Remove camera's cosmetic ring or hood before attaching the Raynox lens *4:Please make shooting under the bright condition when using at the telephoto zoom end. *5:Vignetting occurs at Still mode.*6:Vignetting occurs at under scanning mode *7:Slight Vignetting occurs *8:Please use at most wide position.

Remote control function and internal video light/Flash may not work properly with conversion lens attached.

RAYNOX Camcorder Cross Reference Table for Wideangle Lens

2010/2/5
www.raynox.com



Camera Maker	Camera Model	DVR-5002(0.5x)	DCR-5000(0.5x)	HD-5050PRO(0.5x) / HD-5050PRO-LE(0.5x)	HD-6600PRO-43/49/52/55/58(0.66x)	DCR-730(0.7x)	DVM-700(0.7x)	HD-7062PRO(0.7x)	HD-7000PRO(0.7x)	DCR-7900ZD(0.79x)	HDP-6000EX(0.79x)	DVR-1002(0.65x+1.5x)	QC-505(0.5x) QC-707(0.7x)	XL-5000PRO(0.5x) XL-7000PRO(0.7x)	
Panasonic	HDC-SD9/HS9/SD5(EG)/SX5			Direct mount	HD-6600PRO-52+RA5237A	RA5237A									
	HDC-SD100/HS100			Direct mount *8	HD-6600PRO-52+RA5237A	RA5237A									
	HDC-TM30			RA37305P5(Included)									Direct mount		
	HDC-HS300/350/200/TM300/350/SD200			RA3743(Included)*3 *7	HD-6600PRO-43+RA4343A *3 OR HD-6600PRO-52 +RA4343A + RA5243B *3	RA4343A+RA5243B			RA4343A+RA5843						
	AG-HMC150/151/155, HPX170/175														
	AG-DVX100(A)(AE)(AP)(B)(BE)(BP)											Direct mount			
	AG-HVX200(E)(MC)(P)/HVX202EN											RA7282*7			
	VDR-D310	Direct mount		Direct mount										Direct mount	
	VDR-D400	RA3743(Included)		RA3743(Included)									RA3743(Included)	RA3743	
	VDR-D300/D250	Direct mount		Direct mount									Direct mount	Direct mount	RA5237A
	SDR-S100/S200	Direct mount*3		Direct mount*3									Direct mount*3	Direct mount*3	
	NV-GS320	Direct mount		Direct mount										Direct mount	
	NV-GS500/400	RA3743(Included)*3		RA3743(Included)*3	HD-6600PRO-43								RA3743(Included)*3	RA3743*3	RA5243B
	NV-GS300	Direct mount		Direct mount									Direct mount	Direct mount	RA5237A
NV-GS250	RA3743(Included)*3		RA3743(Included)*3									RA3743(Included)*3		RA5243B	
VDR-M30K															
NV-GS55/GS50								RA30305P5(Included)							
								RA3027P5(Included)							
JVC	GZ-HM400				HD-6600PRO-52+RA5246	RA5246									
	GZ-HD620			Direct mount									Direct mount		
	GZ-HD300/HD320			RA37305P5(Included)											
	GZ-HD40/HD30				HD-6600PRO-43(Direct) HD-6600PRO-52+RA5243B	RA5243A									
	GZ-HD5/HD6				HD-6600PRO-43										
	GZ-HD3/HD7		RA5246			RA5246			RA5852+RA5246					RA5246	
	GZ-MG880/MG840			RA37305P5(Included)											
	GZ-MG275/MG255	RA37305P5(Included)*5		RA37305P5(Included)*5				RA30305P5(Included)*5					Direct mount		
	GZ-MG575/MG555		RA5246		RA5246	RA5246									
	GZ-MG505	Direct mount*3*2		Direct mount*3*2								Direct mount*3	Direct mount*3		
	GZ-MG77/MG67/MG70/MG50/MG40	RA37305P5(Included)		RA37305P5(Included)				RA30305P5(Included)				RA37305P5(Included)	Direct mount		
	GZ-MG47	RA37305P5(Included)		RA37305P5(Included)				RA30305P5(Included)				RA37305P5(Included)	Direct mount		
	GR-D650	RA37305P5(Included)		RA37305P5(Included)				RA30305P5(Included)				RA37305P5(Included)	Direct mount		
	GR-D350	RA3727P5(Included)		RA3727P5(Included)				RA3027P5(Included)				RA3727P5(Included)	Direct mount		
	GR-D250	RA3727P5(Included)		RA3727P5(Included)								RA3727P5(Included)	Direct mount		
	GZ-MC500	Direct mount		Direct mount	HD-6600PRO-52+RA5237A							Direct mount	Direct mount	RA5237A	
	GZ-MC200/MC100	RA37305P5(Included)		RA37305P5(Included)				RA30305P5(Included)				RA37305P5(Included)	Direct mount		
	GR-DV3000/DV3500				HD-6600PRO-52									Direct mount	
	GR-DV5000				HD-6600PRO-52									Direct mount	
GR-DV900K/DV700K				HD-6600PRO-52									Direct mount		
GR-DV500				HD-6600PRO-52+RA5237A									RA5237A		
GR-X5				HD-6600PRO-52+RA5237A									RA5237A		
HITACHI	DZ-BD10H/10HA			RA3743(Included)*5	HD-6600PRO-43	RA5243B									
	DZ-BD7(H)(HA)(HE), DZ-BD70(A)(E)	RA3743(Included)*5		RA3743(Included)*5								RA3743(Included)*5			
	DZ-GX3300	Direct mount		Direct mount								Direct mount	Direct mount		
	DZ-GX3200	RA3734P5(Included)*3		RA3734P5(Included)*3								RA3734P5(Included)*3	Direct mount*3		
DZ-GX3100	RA37305P5(Included)		RA37305P5(Included)				RA30305P5(Included)				RA37305P5(Included)	Direct mount			
TOSHIBA	GSC-R60/R30/MEHV10	RA37305P5(Included)		RA37305P5(Included)				RA30305P5(Included)				RA37305P5(Included)	Direct mount		

*1:Vignetting occurs at 4:3 Still mode *2:Vignetting occurs at Still/Video/under scanning mode *3:Remove camera's cosmetic ring or hood before attaching the Raynox lens *4:Please make shooting under the bright condition when using at the telephoto zoom end. *5:Vignetting occurs at Still mode.*6:Vignetting occurs at under scanning mode *7:Slight Vignetting occurs *8:Please use at most wide position.

Remote control function and internal video light/Flash may not work properly with conversion lens attached.